

Bounce Ride Instructions

The following instructions must be followed to insure your children's safety while using the Moonwalk.

1. Never leave the moonwalk unattended while it is inflated. Parental supervision is required at all times.
2. Moonwalk should be staked into the ground in all 4 corners.
3. This is to be used for children ages 6yrs or under 75 lbs in weight.
No more than six children in the moonwalk at one time is recommended.
4. Children must remove shoes/sneakers, eyeglasses, or any other sharp objects before entering the moonwalk.
5. Flips, Wrestling, and climbing on the walls inside the moonwalk is prohibited.
6. Do not use the moonwalk in extreme weather conditions, i.e., lightning, heavy rain, or any other unsafe conditions.
7. Do not deflate until you are certain that no one is in the moonwalk.

Set Up Instructions:

1. Unfold Moonwalk completely
2. Attach fan-motor to small chute at back of moonwalk
3. Make sure zipper in back of moonwalk is closed
4. Make sure moonwalk is within 50ft of electrical source
5. Extension cord is to be a No. 12 or heavier, no more than 50' long.
6. Plug moonwalk into a regular 120 volt AC circuit (nothing else should be connected to the circuit)
7. When moonwalk is inflated, stake down all four corners with stakes provided
8. To deflate moonwalk, unplug fan from power source and untie chute from moonwalk fan. Open zipper in back of moonwalk and allow air to escape.
9. Please fold in half and roll up and secure with rope provided.