

Sales Office 201-847-9611
Warehouse 201-848-8326
Ridgewood Store 201-447-0360
Hillsdale Store 201-664-0900



Frozen Drink Machine

**This unit draws a lot of power.
Use only a short, heavy #12-gauge extension
cord, or no extension cord at all.
Don't run anything else
from the same electrical outlet.**

Operating Instructions

1. You must use the drink mixes that we sell. Anything else can cause the machine to freeze up.
2. To prepare the drink mix, blend one part drink mix with four parts water. **The machine must be started 2 hours before you expect guests** in order to allow time for the mix to freeze. If adding liquor to the drink mix, start three hours before serving time. (liquor slows down the chilling).
3. The mix in the machine should not get below ½ full. If you can see the auger spinning, it's too low. Add more drink mix right away.
4. Mix must be in both sides of the machine before starting.
5. To start the machine, look for the set of switches on the right side. For all switches, I or II means On. The top-left switch is for power. The two pairs of switches below that are for the two sides of the machine: in each pair, the left switch is for the auger and the right switch is for chilling. **Turn on all four of these switches.**
6. The lights switch (top-right) and the timer clock (below) are not in use.

Cleaning instructions

When you're finished, drain any left-over mix out of the machine. Flush warm water (no soap of any kind) through the dispensers. Flip all switches to their O markings (for Off) and unplug the machine.

If you have any questions or problems, please call immediately.

Thank you for renting from Taylor Rental Have a great party!